

EQUATION™

Instruction Guide



SCAN QR CODE
TO VIEW USER
GUIDE VIDEO

HEADREST [OPTIONAL]

Grab headrest connection and slide/down for height adjustability. Grab front of headrest and pivot up/down to adjust angle.

LUMBAR PAD [OPTIONAL]

While seated, reach behind the chair between the mesh and outer frame and grab the tabs on the side of the lumbar. Slide tabs up/down to adjust pad position

ADJUSTABLE BACK ANGLE

To adjust back angle, lean forward and slide your hands down inside of the backrest, find the buttons and press both to move the back inward or outward.

SEAT DEPTH ADJUSTMENT

To adjust seat depth, lift trigger located on lower side of the seat and simultaneously lift your weight from the seat while sliding the seat forward/backward. Release trigger to lock in place.

HEIGHT ADJUSTMENT

To raise, lift the paddle up while lifting your weight from the seat. Release the paddle to lock into place. To lower, lift the paddle up allowing your weight to push the seat down. Release the paddle to lock into place.



ARMS

HEIGHT ADJUSTABLE ARM:
Press trigger located towards the back of the arm cap to unlock arm height. Lift or lower to desired position and release trigger to lock in place

HEIGHT ADJUSTABLE ARM WITH DUAL PIVOT ARM CAPS:
Arm cap can be adjusted by gently sliding the arm cap forward or backward and pivoting the arm cap left or right. The arm joint adjusts independently from the arm cap — firmly grab the lower half of the arm and pivot left or right. The height of the arm can be adjusted by pressing the trigger located towards the back of the arm cap. Lift or lower to desired position and release trigger to lock in place

TILT TENSION AND LOCK

Turn tension knob clockwise for increased tension and counter-clockwise for decreased tension. Flip tilt lock paddle up to unlock the tilt function. Flip paddle down to lock the tilt function

EQUATION™

Instruction Guide

HEADREST [OPTIONAL]

Grab headrest connection and slide/down for height adjustability. Grab front of headrest and pivot arm/down to adjust angle.



SCAN QR CODE
TO VIEW USER
GUIDE VIDEO

LUMBAR PAD [OPTIONAL]

While seated, reach behind the chair between the mesh and outer frame and grab the tabs on the side of the lumbar. Slide tabs up/down to adjust pad position

ADJUSTABLE BACK ANGLE

To adjust back angle, lean forward and slide your hands down inside of the backrest, find the buttons and press both to move the chair inward or outward.

SEAT DEPTH ADJUSTMENT

To adjust seat depth, lift trigger located on lower side of the seat and simultaneously lift your weight from the seat while sliding the seat forward/backward. Release trigger to lock in place.

HEIGHT ADJUSTMENT

To raise, lift the paddle up while lifting your weight from the seat. Release the paddle to lock into place. To lower, lift the paddle up allowing your weight to push the seat down. Release the paddle to lock into place.



ARMS

HEIGHT ADJUSTABLE ARM:
Press trigger located towards the back of the arm cap to unlock arm height. Lift or lower to desired position and release trigger to lock in place

HEIGHT ADJUSTABLE ARM WITH DUAL PIVOT ARM CAPS:
Arm cap can be adjusted by gently sliding the arm cap forward or backward and pivoting the arm cap left or right. The arm joint adjusts independently from the arm cap — firmly grab the lower half of the arm and pivot left or right. The height of the arm can be adjusted by pressing the trigger located towards the back of the arm cap. Lift or lower to desired position and release trigger to lock in place

TILT LOCK LEVER

TENSION KNOB

TILT TENSION & LOCK

Turn tension knob clockwise to tighten and counterclockwise to loosen. Lean back and push the tilt lock lever down to lock in place, release by pulling the lever up to unlock.



SCAN QR CODE
TO VIEW USER
GUIDE VIDEO

EQUATION™

Dual Pivot Arm Instruction Guide

ARM CAP ADJUSTMENT - SLIDE

Arm cap adjusts independently from arm stem. Gently slide arm cap gently forward or backward through 1.8" range and release when arm is in desired position.

ADJUSTABLE HEIGHT

Press trigger located towards the back of the arm cap to unlock arm height. Lift or lower to desired position and release trigger to lock in place



ARM CAP ADJUSTMENT - PIVOT

Arm cap adjusts independently from arm stem. Gently pivot arm cap left or right through 40 degrees of range and release when arm is in desired position. Slide arm cap gently forward or backward through 1.8" range and release when arm is in desired position.

ARM JOINT ADJUSTMENT - PIVOT

Arm joint adjusts independently from arm cap. Firmly grab the lower half of the arm and pivot left or right through 40 degrees of range and release when arm is in desired position

