

LEVO[®]

User Guide

SEAT SLIDER (OPTIONAL)

To adjust the seat depth, pull the paddle up to unlock it and adjust to the desired position. Release the paddle to lock in position.

BACKREST RECLINE

To adjust the backrest recline, pull the paddle forward to unlock it, lean back to the desired position. Pull the paddle back to lock in position.

BACK LUMBAR SUPPORT

A revolutionary suspension system shifts up or down (in 5 positions) to create our patented invisible lumbar support. The three pivot points create a convex curve that actively supports the entire back. With both hands, simply lift the back frame and let go at your desired tension. Lift all the way up to the top (4 clicks) to release back to neutral.



ARM HEIGHT

Simply lift the arm and release to the desired height. Lift all the way to the top (6 clicks) to release back to neutral.

SEAT HEIGHT

To raise the chair, lift the paddle up while lifting your weight from the seat until you reach the desired height. Release the paddle to lock into place. To lower the chair, lift the paddle up allowing your weight to push the seat down to the desired height. Release the paddle to lock into place.