

PULL ME OUT TO LEARN ABOUT MORE FEATURES

LEVO®

User Guide

ARM HEIGHT

To adjust the arm height, push the button on the arm to raise it to one of the 6 desired height positions.

BACKREST RECLINE

Pull the paddle forward to unlock it. Lean back to the desired position and pull the paddle back to lock in position.



BACK LUMBAR SUPPORT

A revolutionary proprietary suspension system shifts up or down (in 4 positions) to create our patented invisible lumbar support. The **three pivot points** create a convex curve that actively supports the entire back. With both hands, simply lift the back frame and let go at your desired tension. Lift all the way up to the top (4 clicks from base position) to release back to neutral.

For additional information,
please visit [allseating.com](https://www.allseating.com)

For Sales and Customer Service

Email: customerservice@allseating.com

Phone: 1-800-563-3502

For all other inquiries

Email: info@allseating.com

Phone: 905-502-7200

PICTURED | LEVO IN SMOKE
L2 ARMS | SYNCHRO TILT MECHANISM | STANDARD CARPET CASTERS
PATENT PENDING

LEVO® User Guide



LIFT THE BACK FRAME FOR PERFECT LUMBAR SUPPORT.

To try our patented invisible lumbar support, lift the back frame on both sides and let go at your desired tension. Slowly lift all the way to the top (4 clicks from the base position) to release back to neutral.



SEAT HEIGHT

To raise the seat height, lift the paddle while lifting your weight from the seat until you reach the desired height. Release the paddle to lock into place. To lower the seat, lift the paddle allowing your weight to push the seat down to the desired height. Release the paddle to lock into place.



SEAT SLIDER (OPTIONAL)

Lift the lever located in front of the paddle to unlock and slide the seat to the desired position. Release the lever to lock the seat in position.

TILT TENSION

Adjust tension by turning the knob under the front of the chair—clockwise to loosen and counter-clockwise to tighten.