


This disassembly instruction is applicable to EXCHANGE Chair.



For material recycling information please refer to the End of Life Recovery Matrix and List of Recycling Facilities, which is available at www.allseating.com.

Tools: #2 #3 Phillips head, Rubber mallet or hammer, Small flathead screwdriver, Allen key, Box cutter.

Skill Set: Good manual dexterity

Estimated Time: 8 minutes per chair

- Steps:
1. Leg - 2min
Turn the chair over and unscrew the legs from the armrest or seat base
 2. Support Rails - 6min
Locate the support rails from the underside of the chair and unscrew all fasteners that attaches the backrest, seat base, and arms.

For further dismantling, the upholstery, foam could be removed from the backrest, arms, and seat base. The foam and wood panels would be left.