

CHIROFORM ULTRA

Instructional Guide

BACK HEIGHT


To adjust back height, lean forward and grasp the sides of the outside back. To raise, slide the back up. To lower, slide it all the way to the top and then lower to desired height. Available in Midback and Highback.

SEAT HEIGHT

To raise the chair, lift the paddle up while lifting your weight from the seat until you reach the desired height. To lower the chair, lift the paddle up allowing your weight to push the seat down to the desired height.

SEAT DEPTH ADJUSTMENT

To adjust the seat depth, lift up on paddle and simultaneously lift your weight from the seat while sliding the seat forward or backward. Release the paddle to lock the seat in place.



ARM HEIGHT (T2 ARM)

To adjust the height, press the trigger at the front of the arm, adjust to desired height and release. Arm caps slide forward and back for forearm support. Optional width adjustment levers and knobs are available.

TILT LOCK

To adjust the recline angle, push the paddle forwards to unlock it. Recline to the desired position and push the paddle back to lock in place.

TENSION CONTROL

Leaning back in the chair, decide if the resistance of the chair is comfortable. If it is too loose, rotate the tension knob counter-clockwise. If the chair has too much resistance, turn the knob clockwise.